

## **D15 Window Handle Replacement**

Document: D-WE-DSGD15 | Revision: 1 | Issued Date: Dec.11/14 | Page: 1 of 1

- 1) If the handle is still attached it can be removed by cutting the adhesive and tape with a razor blade.
- 2) Clean the area of glass with Isopropyl Alcohol where the handle will be attached.
- 3) Place a bead of adhesive on the new handle in location noted below. (3M 5200 recommended)
- 4) Remove backing from double sided tape.
- 5) Place new handle in desired location and press firmly.
- 6) Let dry for approx. 24 hours before use.

